



RELEASED  
C705/07/11

PPP

Part Number	D350-600-141	Box Part Number	MBX115 B/T	Dimension	
Description	Spacepod, Upward Opening, LH	Other Packaging	MFSP Kit		
		Logo Decals	D3567-1		

### Packaging Instructions and Decal Placement

#### D350-600-141

Secure the box by applying clear tape over it. Place MFSP Kit and then insert spacepod. Wrap spacepod floor in foam and place next to spacepod, then insert hardware kit and paperwork. Close box, strap three times, and apply clear tape over strappings. Apply D2729-3 label as per instructions in QSI 014.

D2729-4

D2729-3

		VERY IMPORTANT - IF REPLACEMENTS ARE REQUIRED, USE THE PART NUMBER ON THE APPROVAL LABEL	
PART	N/A	Q/P/C	CHG005
P/N	D350-600-141	S/C	SH93-88
DESC	Spacepod, LH	S/C	SR00098NY
LOT	BXXXXXX	S/C	SR00099NY
MODEL	AS350	S/C	
TO APPROVAL # 02-89		MADE IN CANADA	

*Ant*  
14/07/29

	<b>Dart Aerospace Ltd.</b> 1270 Aberdeen Street Hawkesbury, ON K6A 1K7 CANADA TEL.: 1 613 632-5200
<b>SPACEPOD, UPWARD OPENING, LH</b>	
<b>P/N: D350-600-141</b>	<b>CHG005</b>
<b>B/N: BXXXXXX</b>	

Revision: F  
Date: 14.07.28